

# Instructions

## For

# Dixon Bayco

# Sensor Tube Cutting

### For Sales and Service Contact

#### USA:

Dixon Bayco USA  
Chestertown, Maryland  
Phone: 410-778-2000  
Fax: 410-778-4702  
Toll Free: 800-355-1991  
E-mail: [dixonbayco@dixonvalve.com](mailto:dixonbayco@dixonvalve.com)

#### Canada:

Dixon Group Canada Limited  
Innisfil (Barrie), Ontario  
Phone: 705-436-1125  
Fax: 705-436-6251  
Toll Free: 877-963-4966  
E-mail: [isales@dixongroupcanada.com](mailto:isales@dixongroupcanada.com)

#### Europe:

Dixon Group Europe Ltd  
Preston, England  
Phone: +44 (0)1772 323529  
Fax: +44 (0)1772 314664  
E-mail: [enquiries@dixoneurope.co.uk](mailto:enquiries@dixoneurope.co.uk)

#### Asia Pacific:

Dixon (Asia Pacific) Pty Ltd Wingfield,  
South Australia  
Phone: +61 8 8202 6000  
Fax: +61 8 8202 6099  
E-mail: [enquiries@dixonvalve.com.au](mailto:enquiries@dixonvalve.com.au)

#### Mexico:

Dixva, S. de R.L. de C.V.  
Monterrey, N.L.  
Phone: 01-800-00-DIXON (34966)  
Fax: 01-81-8354-8197  
E-mail: [contactenos@dixonvalve.com.mx](mailto:contactenos@dixonvalve.com.mx)



*The Right Connection®*

[dixonvalve.com](http://dixonvalve.com)

### Instructions

1. Remove black plastic thread protector.
2. Measure new length of sensor. Sensor length should be set so a minimum of 60 gallons (250 Liters) of outage remain in the tank after the probe is wetted.
3. Hold tube in hand when cutting with a tubing cutter. **Do not put sensor in a vise. This will damage the sensor!**
4. Cut tube with a tubing cutter. Do not use any type of saw. Do not cut tube shorter than 7 inches overall length.
5. Replace thread protector.

### Dixon Bayco Warranty

For complete warranty information, please refer to the latest Dixon catalog.