

Lubricator Bowl / Bowl Guards

| Used On | Description | Part # |
|---------|--|------------------|
| L07 | polycarbonate bowl with manual drain | 3646-54 |
| L73 | transparent bowl with manual drain | 4425-50RL |
| L74 | metal bowl with liquid level indicator and ¼ turn manual drain | 4303-77R |
| | transparent bowl with manual drain | 4325-50R |



3646-54

Pneumatic
Accessories

Seal Wire

Features:

- provides tamper resistant protection of the lubricator drip rate setting

| Used On | Description | Part # |
|----------|-------------|----------------|
| L73, L74 | metal wire | 2117-01 |



seal wire

Domes, Caps and Plugs

| Used On | Description | Part # |
|--------------------|--|-------------------|
| L08 | quick fill cap | 18-011-024 |
| L17, L74 | quick fill cap | 18-011-021 |
| L73, L74 | aluminum fill plug | 5301-55 |
| L17, L72, L73, L74 | sight feed dome (micro-fogging design) | 4055-50 |
| L72, L74 | sight feed dome (oil-fogging design) | 4055-51 |
| L74 | high pressure sight feed dome | 5605-50 |
| | liquid level indicator repair kit | 4380-050 |



18-011-021



5605-50

Lubricator Seal Kits

| Used On | Description | Part # |
|---------|-----------------------------|-----------------|
| L17 | O-rings, seals, and gaskets | 5771-02 |
| L73 | | 4382-600 |
| L74 | | 4382-700 |



5771-02